

SUNEARTH



Cascade Drainback

SRCC OG-300 Certified Solar Water Heating System
Installation, Operation & Maintenance Manual

CASCADE DRAINBACK DOMESTIC SOLAR WATER HEATING SYSTEM

INSTALLATION, OPERATION AND MAINTENANCE MANUAL

The Cascade Drainback solar water heating system has gone through an extensive design, technical and performance review by the Solar Rating & Certification Corporation (SRCC). The installation of your Cascade Drainback system is intended to be executed by properly licensed and experienced professional contractors in accordance with SRCC Standard OG-300, “Operating Guidelines and Minimum Standards For Certifying Solar Water Heating”, and must conform to applicable federal, state and local regulations, codes, ordinances and standards governing the installation of solar water heating systems.

The solar energy system described by this manual, when properly installed and maintained, meets the minimum standards established by the SRCC. This certification does not imply endorsement or warranty of this product by the SRCC.

OG-300 system certification is granted to SunEarth by the SRCC. It may not be used for any commercial purpose without the prior written consent of SunEarth. SunEarth must approve any deviation from the specified materials and methods described in this manual in writing.

The Cascade Drainback solar water heating systems can be protected against freeze damage to temperatures as low as -50°F (-46°C). This system should not be installed in areas within the continental United States where the annual ambient temperature has ever fallen below minus 50° Fahrenheit (-46° Celsius). The Cascade Drainback system must be installed as specified in this manual to have effective freeze protection at these low temperatures.

Freeze tolerance limits are based upon an assumed set of environmental conditions. Extended periods of cold weather, including ambient air temperatures above the specified limit, may cause freezing in exposed parts of the system. It is the owner’s responsibility to protect the system in accordance with SunEarth’s instructions if the ambient air temperature approaches the specified freeze tolerance limit.

TABLE OF CONTENTS

Safety Information	1
Preface.....	3
1) Introduction	3
2) System Description and Operational Principle	3
3) Installation Requirements – General	4
4) Installation Requirements – Specific.....	5
5) System Start Up Procedures	20
6) Two Modes of System Operation.....	20
7) Isolating the Major Components and Shut Down Procedures.....	21
8) Summer Vacation Procedures.....	21
9) Maintenance and Troubleshooting	21
10) Cascade Drainback System Component Parts.....	23
11) Estimated Component Life Expectancy	24
12) System Operating Parameters	24
Appendix A. OG-300 Approved Primary Components.....	25
Appendix B. Pump Sizing Tables.....	28
Appendix C. Cascade Drainback OG-300 Labels	30
Appendix D. SunEarth Collector Warranty Statement.....	32
Appendix G. SRCC OG-300 Certified System Model Numbers	34
Appendix H. Service and Warranty Information	37


IMPORTANT SAFETY INFORMATION.

READ ALL INSTRUCTIONS BEFORE USING.

⚠ DANGER!

WATER TEMPERATURE SETTING

Safety and energy conservation are factors to be considered when selecting the water temperature setting of water heater's thermostat. Water temperatures above 125°F can cause severe burns or death from scalding. Be sure to read and follow the warnings outlined on the label pictured below.



⚠ DANGER: Burns from Hot Water and Steam - Use extreme care when opening relief valves, charging closed loop, and filling storage tank.

The electrical element booster thermostat has been factory set at 50°C (120°F) to reduce the risk of scald injury. Adjusting the thermostat to a higher setting is not recommended. Hotter water increases the potential for Hot Water Scalds.

Time/Temperature Relationship in Scalds

Temperature	Time To Produce a Serious Burn
120°F	More than 5 minutes
125°F	1½ to 2 minutes
130°F	About 30 seconds
135°F	About 10 seconds
140°F	Less than 5 seconds
145°F	Less than 3 seconds
150°F	About 1½ seconds
155°F	About 1 second


Table courtesy of Shriners Burn Institute

The chart shown above may be used as a guide in determining the proper water temperature for your home.

⚠ DANGER: Households with small children, disabled, or elderly persons may require a 120°F or lower thermostat setting to prevent contact with “HOT” water.

NOTICE: Mixing valves should be installed to reduce the point of use water temperature by mixing hot and cold water in branch water lines. Contact a licensed installer or the local plumbing authority for further information.

The temperature of the water in the water heater can be regulated by setting the temperature dial of the adjustable surface mounted thermostat located behind the jacket access panel.



This thermostat controls the water heater's heating element only. (A separate thermostat should be utilized in monitoring the temperature from the collector).

To comply with safety regulations the thermostat is factory set at 120° F or less where local codes require.

⚠ DANGER: Hotter water increases the potential for Hot Water SCALDS.

IMPORTANT SAFETY INFORMATION.

READ ALL INSTRUCTIONS BEFORE USING.

WARNING!

For your safety, the information in this manual must be followed to minimize the risk of fire or explosion, electric shock, or to prevent property damage, personal injury, or loss of life.

Be sure to read and understand the entire Installation, Operation and Maintenance Manual before attempting to install or operate this water heater. It may save you time and cost. Pay particular attention to the Safety Instructions. Failure to follow these warnings could result in serious bodily injury or death. Should you have problems understanding the instructions in this manual, or have any questions, STOP, and get help from a qualified service technician, or the local utility.



FOR INSTALLATIONS IN THE STATE OF CALIFORNIA

California Law requires that residential water heaters must be braced, anchored or strapped to resist falling or horizontal displacement due to earthquake motions. For residential water heaters up to 52 gallon capacity, a brochure with generic earthquake bracing instructions can be obtained from: Office of the State Architect, 1102 Q Street, Suite 5100, Sacramento, CA 95814 or you may call 916-445-8100 or ask a water heater dealer.

However, applicable local codes shall govern installation. For residential water heaters of a capacity greater than 52 gallons, consult the local building jurisdiction for acceptable bracing procedures.



SAFETY PRECAUTIONS

Have the installer show you the location of the circuit breaker and how to shut it off if necessary. Turn off the circuit breaker if the water heater has been subjected to overheating, fire, flood, physical damage or if the ECO fails to shut off.

- | | |
|---|--|
| ☒ Read this manual entirely before installing or operating the water heater. | ☒ Do not attempt to repair or replace any part of your water heater unless it is specifically recommended in this manual. All other servicing should be referred to your installing contractor or local SunEarth Distributor. |
| ☒ Use this appliance only for its intended purpose as described in this Installation, Operations and Maintenance Manual | |
| ☒ Be sure your appliance is properly installed in accordance with local codes and the provided installation instructions. | |

READ AND FOLLOW THIS SAFETY INFORMATION
CAREFULLY.

SAVE THESE INSTRUCTIONS

PREFACE

Let us first offer two words of grateful appreciation. Thank You! We sincerely appreciate your business. SunEarth also wishes to say thank you for “going solar”. Solar water heating systems reduce our nation’s dependence on polluting fossil fuels, minimize the greenhouse gas emissions associated with conventional water heating and, very importantly, lower your monthly utility costs.

Established in 1978, SunEarth is a leading U.S. solar equipment manufacturer. Our products include industry standard Empire, SunBelt, Imperial and ThermoRay solar water heating collectors, CopperHeart integral collector storage systems, SunSiphon packaged thermosiphon systems, SunBurst all copper absorber plates, Solar Strut and “RexRack” mounting systems. We also build specialty collectors for unique architectural and building applications. SunEarth Solar Rating and Certification Corporation (SRCC) Standard OG-300 certified solar water heating systems are sold by leading solar, plumbing and building contractors throughout the United States.

Your Cascade Drainback solar water heating system has been designed to meet exacting SRCC OG-300 certification requirements. The specific components found in your system have been selected by your installation contractor for their proven reliability, longevity and performance in your specific region of the country.

SunEarth maintains a policy of continuous review and improvement to ensure that Solaray systems incorporate any appropriate technological advances. To ensure that products represent the current state of the art in solar water heating SunEarth systems are subject to change without notice. Please consult the SunEarth Inc. website at www.sunearthinc.com for current information and latest manual revisions.

1) INTRODUCTION

Solar water heating systems are climate and site specific appliances. Different types of solar systems are installed around the world in accordance with regional weather and water quality conditions. System performance varies as a function of the household hot water load, including daily showers, laundry and kitchen uses, the average ground water and ambient air temperatures, the home’s roof pitch and orientation, and, of course, the seasonal intensi-

ty of solar radiation. These variables, some of which change from home to home on the same neighborhood street, will determine how much energy and money your Cascade Drainback system will save on an annual basis.

Your Cascade Drainback solar system is known as a “forced circulation closed loop drainback” system because it utilizes a mechanical pump to efficiently circulate water throughout the unpressurized closed loop solar piping. The “drainback” connotation refers to the freeze-protection mechanism used in the system. In drainback systems, the heat exchange fluid (water) in the collector array and solar loop piping drains back by gravity into the drainback storage reservoir when the pump stops circulating. Air replaces water in the collector array and solar loop piping to prevent it from freezing when the pump is off.

This manual is intended as a basic “solar water heating primer”. Our goal is to familiarize you with the proper installation, operation, and maintenance of your Cascade Drainback solar system. This system is required to be installed by properly licensed solar or plumbing contractors in accordance with SRCC Standard OG-300 and all applicable national, state and local codes, ordinances and regulations governing solar installations as well as good trade practices. Failure to follow the procedures and practices described in this manual may void manufacturer warranties for specific component parts.

This manual covers installations utilizing one or two SunEarth solar collectors with a single solar storage tank and also two tank systems that include a solar storage tank and supplemental tank type or tankless water heater. For simplicity, the singular form will be used throughout this manual when referring to the system components and permutations. Frequent reference will be made throughout this manual to specific component parts. The placement of each component in the system is found in Figures 10, 11 and 12. An explanation of the component function is found in pages 23-24.

2) SYSTEM DESCRIPTION AND OPERATIONAL PRINCIPLE

The key components in the Cascade Drainback solar water heating system include the SunEarth solar collector, drainback reservoir, solar storage tank with integral heat exchanger, circulation pump, differential temperature controller and mixing valve.

The SunEarth solar collector is the heart of the Cascade Drainback system. Simply stated, when the sun is shining, heat energy is absorbed by the solar collector's all copper absorber plate and transferred to the water circulating through the solar collector. The system pump efficiently circulates this heated water through the collector piping and integral tank heat exchanger. As the water passes through the heat exchanger, the heat in the fluid is transferred to the potable water in your solar storage tank. As this process is repeated during the average sunny day, the temperature in your solar storage tank rises.

The differential temperature controller is the brain of the system. The controller uses temperature sensors to constantly monitor the temperatures at the collector and at the tank. The controller automatically turns the pump on when useful heat is available at the collector and turns the pump off when there is insufficient solar heat available or the tank has reached maximum temperature.

Depending upon the system demand, time of year and the weather, the circulating pump may either run intermittently throughout the day or constantly for hours at a time.

Both single and double tank Cascade Drainback systems are designed to accommodate two separate modes of system operation. Your system can either (1) serve as a preheater to your conventional electric

or gas water heater or (2) be bypassed entirely and run 100% on utility power during inclement weather or when maintenance is required. The installation of an optional water heater time switch allows you to control both the frequency and duration of supplemental electric resistance water heating.

Section 6 provides instruction in setting the system for automatic operation in each of these two modes.

The water in the SunEarth collector and the solar loop piping automatically drains back into the drainback reservoir each time the circulating pump turns off. Gravity drains the piping and provides the freeze and overheat protection for your Cascade Drainback system.

The system also can be manually drained in order to protect the integrity of the collector and solar loop piping if it is exposed to extended periods of disuse or persistent hard freeze conditions below - 50° Fahrenheit. (See Section 7 for instructions).

3) INSTALLATION REQUIREMENTS – GENERAL

3.1 Permits:

The contractor shall obtain all required permits and approvals.

3.2 Codes, Ordinances and Standards:

fig. 1



SYSTEM ORIENTATION

The installation shall conform to all federal, state and local regulations, codes, ordinances and standards governing the installation of solar water heating systems. The contractor shall adhere to sound building safety and trade practices. Special consideration must be given to building code requirements for roof loading and the penetration of structural members and fire rated assemblies.

3.3 Shading Considerations:

The collectors must be located in an area of the roof that will not be shaded for the majority of the day all year round. Adjacent buildings and trees should be checked for possible winter shading. The collector should not be shaded by any permanent obstacle between 9:00 a.m. and 3:00 p.m. on any day of the year. An instrument such as the Solar Pathfinder can be used for solar site analysis.

3.4 Roof and Site Inspection:

Before the installation, the contractor shall inspect the condition of the roof and notify the homeowner of any existing roof damage or necessary repairs.

3.5 Structural Considerations:

The collectors must be located in a structurally sound area of the roof. Penetrations into structural members must not compromise the structural properties of the structural member.

ENSURE THAT ALL STRUCTURAL MEMBER PENETRATIONS COMPLY WITH APPLICABLE CODES.

The collector mounting method must be capable of maintaining the required tilt and azimuth of the collector under the expected dead loads, wind loads and snow loads for the location.

3.6 Building Envelope:

Penetrations through the building envelope (including roof, walls or floor penetrations) must not impair the enclosure function and must meet applicable codes and best practices.

Roof penetrations whether for structural mounts or pipe penetrations must be sealed and leak proofed as per applicable codes and National Roofing Contractors Association practices.

Building penetrations must allow vermin intrusion.

3.7 Fire-Rated Assemblies:

Penetrations through fire-rated components must not reduce the fire resistance of the assembly below code.

3.8 Building Materials:

Building materials adjacent to solar components must not be exposed to elevated temperatures.

3.9 Confirmation of Installation Site:

The homeowner and contractor shall confirm the location of all roof and ground mounted components in advance of the installation.

3.10 Fluid Identity and Toxicity:

The Cascade Drainback system uses water as a heat transfer fluid, this is heated in the collector and indirectly heats the domestic hot water through the integral heat exchanger in the solar tank. Use of toxic heat transfer fluids is prohibited.

3.11 Maintenance and Servicing

When installing the system, make sure that all the components all the components are accessible and easy to reach. Provide for clear access to the storage tank, pump, drainback reservoir, mixing valve and other key components. If a component in the potable water side of the system may require future service or maintenance make the connections with brass unions or other approved connections.

4) INSTALLATION

REQUIREMENTS – SPECIFIC


4.1 Collector Orientation

The performance of solar water heating systems in the Northern Hemisphere is optimized when the collector is mounted facing True South. Performance, however, suffers very little when the collector is oriented no more than 45° East or West of True South. The collector should be unshaded by any permanent obstacle between 9:00 a.m. and 3:00 p.m. on any day of the year.

4.2 Collector Tilt

Optimal annual efficiency is achieved by tilting the solar collector at an angle that equals your latitude plus an additional 10°. This tilt angle favors the lower winter sun when collector performance is at its lowest and minimizes overheating during the hot-

fig. 2



STAND OFF ON BARREL TILE ROOF

test summer months.

To ensure proper water drainage from the glazing of the collector, the collector must be sloped from horizontal. Never mount the collector parallel to a flat roof. Use SunEarth RexRack, Landscape rack or Universal tilt products to tilt the collector to the proper angle.

The minimum acceptable tilt angle from horizontal is 15°.

4.3 Basic Mounting Procedures

The SunEarth solar collector in your Cascade Drainback solar system should be mounted in a vertical orientation parallel to the slope of the roof if possible. This orientation allows the internal riser tubes to rapidly drain when the circulation pump shuts off.

CRITICAL: BOTH THE COLLECTORS AND THE SOLAR LOOP PIPING MUST BE SLOPED TO DRAIN AWAY FROM THE HIGHEST POINT IN THE SYSTEM BACK TO THE DRAINBACK RESERVOIR.


The minimum required slope is 1/4" vertical drop per foot of horizontal piping run (2% minimum slope). Use the steepest slope possible on the return line piping to the drainback reservoir. Water will drain down both the return tubes directly to the drainback reservoir and the supply tubes by spinning the pump impeller in the reverse direction.

The collector should be mounted as close to the storage tank as possible to minimize heat loss in the piping runs. The solar collector should be mounted on the roof in accordance with these general principles:

4.3.1 The most important structural consideration is to securely anchor the solar collector and the SunEarth mounting hardware to the structural members of the roof with stainless steel hanger bolts, lag bolts, standoff mounts or other approved roof attachment method. The solar collector shall be attached to the mounting hardware as detailed in Figures 2 – 4. (Note: The drawings in this manual detail mounting hardware for the SunEarth Empire, Imperial, SunBelt and ThermoRay series collectors).


4.3.2 The collector should be raised from the roof surface to allow for rainwater and debris to pass

fig. 3




STAND OFF ON FLAT TILE ROOF

fig. 4



STRUT ON FOOT MOUNT FOR COMPOSITION ROOF

fig. 5



under the collectors and for proper ventilation of the roofing material. There should be at least 1 ½" of clearance between the roof surface and the bottom of the solar collectors. Local codes may require greater clearance for snow shedding, etc.

4.3.3 When selecting mounting hardware and fasteners it is extremely important to avoid galvanic corrosion resulting from the direct contact of incompatible metals. Use of SunEarth anodized aluminum Solar Strut mounting hardware and stainless steel lag or hanger bolts, and fastening hardware is recommended. In climates subject to severe winters or high humidity use of galvanized fasteners is prohibited.

4.3.4 Preserving the integrity of the roof membrane is the most important roofing consideration. Ensure that all roof penetrations required to plumb and mount the solar collector are properly flashed and sealed in accordance with best roofing practices.

4.3.5 If the region is subject to hurricane conditions, additional steps may be required to secure the collector and mounting hardware to the structural members. In certain areas of the country, local

building codes may require collector wind load testing or prescribe specific mounting procedures. Consult your local building department.

4.4 Collector Loop Plumbing

The collector loop must be plumbed using copper or stainless steel piping and copper, brass, bronze or stainless steel fittings. Lead-free solder shall be used. Use of galvanized steel, CPVC or PVC is prohibited. PEX may be used only in systems that meet the following conditions:

- The PEX tubing shall not be exposed to sunlight.
- Water must be used as the heat transfer fluid.
- The system shall be non-pressurized (capped at atmospheric on the day of installation) or shall be vented to atmosphere.

A length of uninsulated copper tube no less than ¾" nominal diameter shall be used at the hot outlet of the solar collector(s) for a distance of no less than three feet (3') before the transition is made to PEX tubing.

All connections in the PEX piping runs shall be approved by the PEX manufacturer for potable water piping.

- The system shall have a pressure-only relief valve installed at the drainback tank location or shall be vented to the atmosphere. The pressure rating for the relief valve shall be no less than 25 psi and no more than 50 psi.

The collector loop pipe sizing must be adequately sized to handle the design flow rates for the collector(s). SunEarth recommends $\frac{3}{4}$ " nominal diameter pipe sizes for two collector systems and $\frac{1}{2}$ " nominal diameter pipe sizes for two collector systems, except for the return piping from the collector to the drainback reservoir, this should always be $\frac{3}{4}$ " or larger.

CAUTION: The solar loop piping from the collector(s) to the drainback tank must be no less than $\frac{3}{4}$ " TYPE-M copper tube to allow air to migrate up the tube ensuring full draining of the collector(s) and tubes.

It may be necessary to increase the pipe size for longer pipe runs or reduce the pipe size for shorter runs or higher efficiency pumps. The pipe must be large enough that the velocity of the water in the pipe does not exceed 4 ft/s. Hot water flowing at over 4 ft/s in a pipe will erode the pipe and reduce system life.

When more than one collector is used in the system, the collectors should be plumbed in a reverse return piping arrangement in order to maintain equal flows through all collectors in the array during normal operation.

To ensure proper drainage of the collector array and solar loop piping the lines must be adequately sloped to drain back to the drainback reservoir.

Figure 7 illustrates correct and incorrect methods of plumbing the solar collector array. Note that water will trap in the "U" section of piping as illustrated in the drawing marked incorrect thus making it susceptible to freeze damage.

Piping in new solar installations can be covered with dirt, grease, solder flux or other impurities that may



affect the system performance. A thorough cleaning is required before charging. A Water soluble flux should be used when soldering pipe joints in the collector loop in order to facilitate system flushing. Carefully review the cleaning procedures in “Charging the System” outlined below.

All vertical piping between the storage tank and the collector shall be supported at each story or at maximum intervals of ten feet (10'). Horizontal runs shall be sloped to drain (minimum 2% slope) and supported every five feet (5') to prevent sagging. Roof runs shall be secured and supported providing at least 1-1/2 inches clearance from roof. Pipe supports shall be constructed from a material that will not rot, compress or degrade over time as this may lead to pipe sagging and failure to drain. Standard best piping practices shall be followed as described in the Uniform Plumbing Code, International Plumbing Code or other recognized code or standard. Plumbers tape or tube strap is required. The pipe insulation should not be compressed or crimped by the strapping material.

Only Solder Fluxes meeting the criteria of ASTM B 813 should be utilized for joining by soldering any copper and copper alloy tube and fittings in the entire solar system.

Allowance should be made for expansion and contraction of piping due to changes in temperature of the water and piping. Use flexible pipe supports and avoid long straight piping runs. Include bends and elbows to allow for expansion such as swing joints at the collector inlet & outlet.

The installation of all horizontal and vertical piping may not reduce the performance or rating of any structural member or fire rated assembly. Adhere to all applicable local codes and ordinances.

4.5 Pipe Insulation

WARNING: HOT PIPES MAY CAUSE BURNS IF TOUCHED. ENSURE THAT ALL PIPES AND FITTINGS ACCESSIBLE TO THE PUBLIC ARE WELL INSULATED. COMPONENTS ACCESSIBLE TO PUBLIC TRAFFIC MUST BE KEPT BELOW 140°F OR CLEARLY LABELLED WITH AN APPROPRIATE WARNING.

The collector loop piping, plus any interconnecting hot water piping shall be well insulated with a high quality flexible closed cell insulation to minimize

heat loss. In addition, the final 5 feet of metallic cold water supply pipe leading to the system, or the length of piping which is accessible if less than 5 feet, shall also be insulated. The insulation shall have a maximum operating temperature of 220°F or higher and a minimum thermal resistance of R-2.6. The wall thickness of the pipe insulation should be ½” or thicker. A 1” wall thickness is required for exposed piping in all areas prone to annual hard freeze conditions. When it comes to pipe insulation the rule is simple: thicker is better.

To the extent possible, slide the insulation material over the pipe without cutting or taping. All butt joints must be sealed with contact adhesive. The use of rigid polyethylene pipe insulation is prohibited. The temperatures generated by your collector in the summer months or under stagnation conditions can melt this type of material.


Any above ground exterior pipe insulation shall be protected from UV degradation and moisture damage. Insulation must be jacketed, wrapped with aluminum foil tape, or painted with two coats of high quality water-based acrylic resin coating as supplied by the insulation manufacturer.

4.6 Control System

4.6.1 Differential Controller

The differential controller must be installed in an accessible location so that the user interface, typically and LCD screen, can be seen. Switches on the controller must be labeled and accessible. Always follow the controller manufacturers wiring diagram when installing differential controllers. Control system inputs; such as signals from temperature sensors or flow meters will be connected to the appropriate low voltage terminals. Controller output to the pump will be medium voltage, 110 VAC or 220 VAC. Medium voltage power to the pump may be supplied by a line cord from the pump to an outlet in the controller or hard wired from the controller medium voltage terminals to the pump. Wiring must comply with standard electrical practice and all applicable electrical codes for the jurisdiction, this may require the use of conduit for medium voltage wiring.

The differential controller must have a provision to manually turn the pump on and off (manual override) so that pump operation can be checked at any time and the pump can be manually stopped if



required for maintenance or troubleshooting purposes.

Set the maximum tank temperature to the desired maximum temperature, this temperature must be lower than the rated maximum temperature of the tank. When the solar loop heats the tank to this temperature, the pump will shut off preventing further heat gains to the solar tank.

4.6.2 Collector Sensor Placement

The collector sensor shall be located on the hot water return line as close to the collector as possible. Sensors are typically accurate to $\pm 1/2^\circ\text{F}$ if properly installed and weatherized. The collector probe sensor shall be attached to the SunEarth collector header pipe either with a stainless steel hose clamp or by inserting the probe sensor into a thermalwell in contact with the fluid near the outlet header pipe.

It is recommended that the connection between the silicon sensor lead and low voltage sensor wiring be made inside the attic or other indoor space. When using wire nuts to make the connection, the crimped brass cap on the end of the sensor wire should be striped before inserting into the wire nut. Where connections from the sensor lead to the low voltage wiring is made at an exposed location the wire connection should be protected from degradation or corrosion from rain, snow and UV radiation. Connections may be protected by using: crimp and heat shrink or solder and heat shrink butt connections; NEMA 4X or other weather resistant connection boxes. Weather resistant connection boxes with integral lightning arrestors are also available and are highly recommended in areas prone to electrical storms. Wire nuts or screw connectors should not be exposed to weather due to the likelihood of corrosion which will result in a compromised electrical connection.

Thoroughly wrap and weatherize the insulation with electrician's tape or insulation tape as provided by the manufacturer. See Figure 8 for collector sensor installation detail.


If an electrical potential exists between the roof and ground, this may induce current to flow down the sensor wire to the controller. This current will result in a false signal being received by the controller and incorrect temperature readings. To prevent such current the copper plate and piping should be independently grounded. This will provide a separate path to ground from the roof which does not interfere with the sensor readings.

Grounding can be achieved by running a separate ground wire to the collectors or ensuring that the copper pipe in the closed loop is grounded and there are no electrical discontinuities between the grounding point and the collector. Grounding of the collector & roof piping is especially important in locations that often experience electrical storms and electrical atmospheric activity.

4.6.3 Low Voltage Wiring

The low voltage wiring used to connect the sensor lead to the controller shall be a minimum 18 AWG. The wiring should be bare or tinned copper, two conductor, stranded, PVC insulated, with a PVC UV rated jacket suitable for exterior use. In locations that often experience electrical storms and electrical atmospheric activity the low voltage sensor wire should also be shielded and the shielding connected to ground.

Low voltage wire shall be rated for the full range of temperatures expected in the location, typically wire should be rated up to 160°F . The low voltage sensor wire must not be in direct contact with the copper pipe as the wire insulation may melt when in contact with hot pipe. Low voltage sensor wire



must be run **OUTSIDE** the pipe insulation, where the low voltage wire is run in an exposed location, it should be run **OUTSIDE** the pipe insulation but **UNDER** the insulation jacket or wrap to protect the wire from UV exposure.

4.7 Installing the Solar Tank

The solar tank is heated indirectly through a double wall heat exchanger that is integral to the tank. This kind of heat exchanger wraps around the tank shell and under the insulation and tank jacket. Any leak in the heat exchanger will be seen as fluid will leak out from the bottom tray of the tank jacket.

When plumbing the SunEarth solar storage tank and drainback reservoir make sure that all the components are accessible and easy to reach. Ensure that there is clear access to the storage tank, circulating pump, drainback reservoir, mixing valve, flow meter and other key components. If a component in the potable water side of the system may require future service or maintenance make the connections with brass unions. Use only brass nipples and unions and copper and brass fittings in plumbing the solar storage tank and drainback reservoir. The use of galvanized fittings or nipples, CPVC or PVC piping is prohibited.

Check valves are **NOT ALLOWED** anywhere in the collector loop. A check valve in the collector loop will prevent proper draining of the collectors and may result in freeze damage. If the pump used has an integral check valve, the check valve must be removed before installing the pump in the system.

Hard copper connections to the city cold water supply line and the home hot water feed lines are recommended. The gaskets in standard water heater flex hose connectors can become brittle and compressed over time and begin leaking on the water heater. If not detected in a timely manner even a small drip or leak may cause serious damage to the tank's electrical components or, in extreme cases, may cause the tank to leak from the outside in.

Tank plumbing is required to provide for the isolation of the solar storage tank from the city cold water supply line by means of an isolating ball valve.

The differential temperature controller shall have a screen readout to show temperatures of the collector and storage tank. Otherwise, line thermometers shall be installed in the collector supply and return lines to allow for a simple diagnostic check of proper system operation. On a sunny day the hot

water return line should be approximately 5 – 15°F warmer than the water in the collector supply line.

The specified SunEarth controller continuously displays the temperature of the SunEarth collectors (T1) and the temperature at the bottom of the solar tank (T2). In addition, you may choose to install a third temperature sensor (T3); this is normally installed at the hot water outlet on both single and double tank systems.

Table 1

Array	DB 5.0	DB 7.5	DB 10.0
1 EP/EC-40	82	138	194
2 EP/EC-21	76	132	188
2 EP/EC-32	73	129	185
2 EP/EC-32	62	118	174

Pipe run lengths for 1/2" supply and 3/4" return lines.

Table 2

Array	DB 5.0	DB 7.5	DB 10.0
1 EP/EC-40	61	103	144
2 EP/EC-21	57	98	140
2 EP/EC-32	54	96	138
2 EP/EC-32	46	88	130

Pipe run lengths for 3/4" supply and return lines.

The Cascade Drainback system typically requires a high head, low flow circulating pump. The maxi-

um head on the pump curve must be greater than the static lift head required to fill the system. The static lift head is the vertical height from the bottom of the drainback tank to the highest point in the system (usually the collector outlet header). When the pump is filling the system it will be pumping against the static lift head and should provide no less than half the design flow of the collector. Once the system has been filled to the top of the collector, water will start to cascade down the return line filling the return line as far as the drainback reservoir. Once this pipe is fully flooded the return line will start to siphon, resulting in an increase in flow as the system transitions from the filling condition to the running condition. In the running condition the flow rate should not exceed 4 ft/s. Good pump selection requires that the pump provide enough lift for the filling condition without excessive flow in the running condition. This is usually achieved using a pump with a "steep" pump curve. For multistory buildings, this can be especially challenging unless the drainback tank is located on the upper floor.

When there is a risk of pipe erosion due to high flow rates, a pump throttling valve (COMPONENT #22) may be located on the discharge, or upstream, side of the pump to adjust the solar loop flow rate and to prevent erosion of solar loop. A throttling valve on the return piping from the collector to the drainback tank can also be beneficial in situations where excessive noise is experienced due to high flow rates into the drainback reservoir.

A brass boiler drain (COMPONENT #11) must be installed at the lowest point in the system to allow for charging the solar loop piping and to serve as a drain valve for manual draining and maintenance.

Table 3 - Specification For SunEarth CopperStor Drainback Tank

SunEarth Model No.	Width Inches	Length Inches	Depth Inches	Dry Weight (lbs)	Fluid Capacity (US gal)	Wet Weight (lbs)	Max Pressure (psig)	Connection Pipe Dia. (in)
DB-5.0	12	50	5	42	5.0	82	220	3/4
DB-7.5	18	50	5	56	7.5	117	220	3/4
DB-10.0	24	50	5	84	10.0	164	220	3/4

Max. Temp of 210° F

A high quality thermostatic mixing valve is a required component in all OG-300 certified systems and should be plumbed in line with brass union connections for ease of future repair or replacement. The mixing valve shall be standard ASSE 1017 approved. The specified mixing valve should have an operating range between 95°F and 120°F. The mixing valve shall include a set point of 120°F delivered water temperature.

WARNING: SCALDING CAN OCCUR WITHIN FIVE SECONDS WHEN WATER TEMPERATURES APPROACH 140° F. DESPITE THE INSTALLATION OF A MIXING VALVE IN YOUR CASCADE DRAINBACK SYSTEM, ALWAYS EXERCISE CAUTION WHEN OPENING A HOT WATER FIXTURE OR FAUCET IN YOUR HOME.

The 3/4" cold water supply line to the solar storage tank shall be insulated with R-2.6 or greater pipe insulation to a minimum distance of 5' behind the storage tank, or to the wall if closer than 5'.

The SunEarth solar storage tank model with integral heat exchanger and auxiliary heating element is the specified storage tank in your Cascade Drainback system.

Figures 10, 11 and 12 show the plumbing schematics for single and two tank Cascade Drainback systems. A brief explanation of the main components and their function is found in Section 10 below.

4.8 Tank Sensor Placement

Figure 9 details the proper placement of the solar storage tank sensor. The tank sensor shall have good thermal contact with the tank wall in order to accurately measure the temperature of the water at the bottom of the tank. It is recommended that the sensor be installed in a brass or copper thermalwell screwed into the lower sensor port in the tank. With tanks that have a sensor stud; the probe sensor may be clipped to the stud using a one hole jiffy clip (for 3/16" tubing) ensuring good thermal contact between the sensor and the stud. Thoroughly weatherize the wire connections in accordance with the roof sensor detail above.

4.9 Tank Insulation

SunEarth solar heat exchange tanks have an insulation value of approximately R-17.3.

Conventional back-up electric water heaters have insulation values between R-12 and R-20. The R value expresses the thermal resistance of the tank insulation. The higher the "R-value" value the more effective the insulation material is at preventing heat loss. The use of any solar storage tank with an R value below R12 is prohibited.

The storage tank should not be placed directly on an uninsulated floor or concrete slab. In order to prevent moisture damage to the base of the tanks and reduce heat loss to the floor slab, the tank should be raised off the floor on a pad. The pad should be of a material that will not rot, compress or degrade over time.

4.10 Choosing and Installing the Drainback Reservoir

SunEarth CopperStor copper drainback reservoirs are available in 2.5; 5; 7.5 and 10 gallon capacities. Stainless steel drainback reservoirs are available in 10 and 15 gallons. Small glass lined steel electric water heaters available in various sizes from 6 to 20 gallons can also be used as drainback reservoir; do not connect the heating element when using these tanks as a drainback reservoir. The minimum drainback reservoir volume must be DOUBLE the volume of the piping and collector loop above the initial fill level of the system. This volume is calculated from the fluid capacity of all the collectors in the system plus all piping above the drainback tank fill level.

Select the appropriate tank based on the collector(s) chosen and the total length of solar supply and return loop piping in the system. Table 1 and Table 2 indicate the proper drainback tank for the two most common piping scenarios. SunEarth recommends using *Table 1: 1/2"* piping for the supply line and 3/4" piping for the return line. This provides some flow related benefits, extends the allowable pipe run and is slightly less expensive.

The drainback reservoir shall be mounted in a location that is NEVER subjected to freezing conditions. The drainback reservoir may be mounted to a wall using brackets or on a stand over the solar tank. The outlet of the drainback reservoir should be at least 48" above the suction side of the circulating pump to give sufficient net positive suction head available to the pump (See Figures 10, 11 and 12).

The drainback reservoir should be installed at the highest location practicable. The benefits of this include: reduced risk of pump cavitation; reduced pumping head required to fill the system allowing smaller pumps to be used; and reduced piping above the drainback reservoir allowing smaller drainback tanks. In buildings with two or more floors, it is beneficial to install the drainback on the uppermost floor, preferably near the ceiling.

Drainback reservoirs are factory insulated to provide both heat retention and a noise buffer against the sound of falling water.

If your Cascade Drainback system includes the optional flow meter it should be plumbed so that the top of the flow meter is level with the top of the drainback tank so that the flow meter also provides a visual check of the fluid level in the system. The top and bottom of the flow meter should be supported to relieve stresses on the connecting unions.

DO NOT install the pressure relief valve (COMPONENT #9) on the drainback tank at this time. The COMPONENT #9 is threaded in place after the solar loop piping has been filled with water. See Section 4.13 for instructions on charging the system.

4.12 Electrical Requirements

When electric element is used as the auxiliary heat source a properly licensed contractor shall make the 230 VAC electrical connection to the water heater or solar storage tank. If your solar contractor is not allowed by law to make these connections consult a licensed electrician.

Never activate the circuit breaker controlling the electrical heating element until the solar storage tank is completely filled with water. This will prevent “dry firing” of the heating element. The electrical heating element will be destroyed almost instantaneously if not completely submerged in water when activated. Make sure the water heater circuit breaker is off until the solar storage tank is completely filled.

We recommend the use of a 115 VAC differential control with a factory installed six foot line cord. The installation requires one 115 VAC outlet to be installed near the solar storage tank. Plug the control into the outlet. The circulation pump line cord is plugged into the receptacle on the side of the controller. A 230 VAC control and circulation

pump may be substituted, but troubleshooting the components in the future becomes more difficult.

4.13 Heat Transfer Fluid (HTF)

The HTF must be a non-toxic fluid that meets FDA Generally Recognized as safe (GRAS) Classification. The Cascade Drainback System uses water to meet this requirement.

Water used fill the collector loop must meet certain minimum standards for purity. Impurities in the dilution water can increase metal corrosion, and cause the formation of scale and other deposits on the heat exchanger’s internal heat transfer surfaces. Distilled or deionized water is recommended.

4.14 Flushing and Filling the System

Once the components have been plumbed it is time to fill the solar storage and collector loop with water as follows:


4.14.1 STEP 1 – Fill the solar tank with water and check that there are no leaks on the potable side of the system.

Do this by opening the cold water isolation ball valve to the solar tank (COMPONENT #8) and opening a hot water outlet, such as a faucet, until the water runs freely. When the tank is filled, inspect all threaded fittings and solder joints for leaks.

4.14.2 STEP 2 - Fill the solar loop piping with water.

First connect a washing machine hose to the boiler drain (COMPONENT #11) located at the lowest point in the system. Open the boiler drain (COMPONENT #11) and begin filling the system directly from a fixture at mains pressure or by using a utility pump. If your system has a flow meter (FM), or sight glass, continue filling the solar loop piping until the water level is visible. When the water rises to within 1” of the top of the flow meter or sight glass, close the boiler drain (COMPONENT #11). Install the mandatory pressure relief valve (COMPONENT #9) on top of the drainback reservoir. If your system does not have a flow meter or sight glass attach a washing machine hose to the female fitting on top of the drainback reservoir using an appropriate hose to pipe fitting (3/4” Male Hose Thread X 3/4” FIP). Place the other end of the hose in a basin drain or mid-size bucket. Open the lower boiler drain (COMPONENT #11) and begin filling the solar loop piping from a tap or by using a utility

fig. 9



**TANK SENSOR
THERMOWELL**

**TANK SENSOR
JIFFY CLIP**

pump. Continue filling the piping until water flows from the upper hose into the basin or storage bucket. Close the boiler drain and install the COMPONENT #9 on the drainback reservoir.

4.14.3 STEP 3 – Run the pump to check operation and flush impurities from the collector loop.

At this point it is recommended to run water through the system to remove any solder flux residue or other impurities that were introduced into the system during plumbing. Water soluble flux should have been used when soldering pipe joints in the collector loop to facilitate system flushing. Set the switch on the side of the SunEarth control to the “ON” position. Allow the pump to circulate water through the system for 15-20 minutes. While the pump is running check the entire collector loop for leaks and ensure that there is adequate flow.

4.14.4 STEP 4 – Check that Collectors are Draining Back.


Turn the controller back to the ‘OFF’ position. Allow time for the collectors and piping to drain into the drainback reservoir. Observe the water level in the drainback reservoir by means of the site glass, visual flow meter or by checking with a dowel rod. The water level in the drainback reservoir should return to the original fill level after a few minutes. If the water level does not return to the original fill level, the system is not draining properly and may freeze. If water level does not return to original level, check format that the collectors are tilted with riser tubes at 15° or more and that all piping is sloped to drain at 2% or more.

4.14.5 STEP 5 - Drain the system to remove impurities.

Drain the cycled water out of the array by placing the hose attached to the lower boiler drain

fig. 10


- (1) SunEarth Solar Collector(s)
- (2, 3, 4) Temperature Sensor
- (5, 6, 7, 8, 22) Ball Valve
- (9) Pressure Relief Valve
- (10) Drain Back Tank
- (11) Boiler Drain
- (12) Pump
- (17) Differential Temperature Controller
- (18) Heating Element & Tank Thermostat
- (19, 20) Temperature and Pressure Relief Valve
- (21) Mixing Valve



SINGLE TANK SCHEMATIC

fig. 11

- (1) SunEarth Solar Collector(s)
- (2, 3, 4) Temperature Sensor
- (5, 6, 7, 8, 22) Ball Valve
- (9) Pressure Relief Valve
- (10) Drain Back Tank
- (11) Boiler Drain
- (12) Pump
- (17) Differential Temperature Controller
- (18) Heating Element & Tank Thermostat
- (19, 20) Temperature and Pressure Relief Valve
- (21) Mixing Valve



TWO TANK SCHEMATIC

- (1) SunEarth Solar Collector(s)
- (2, 3, 4) Temperature Sensor
- (5, 6, 7, 8, 22) Ball Valve
- (9) Pressure Relief Valve
- (10) Drain Back Tank
- (11) Boiler Drain
- (12) Pump
- (17) Differential Temperature Controller
- (18) Heating Element & Tank Thermostat
- (19, 20) Temperature and Pressure Relief Valve
- (21) Mixing Valve
- (22) Tankless Water Heater



(COMPONENT #11) into a service drain or bucket. Open the lower boiler drain and completely drain the water from the system.

CAUTION: THIS WATER MAY BE EXTREMELY HOT!

4.14.6 **STEP 6** - Refill the system with water.

Repeat the STEPS 1 and 2 above to refill the collector loop with water to the correct level with deionized water.

5) SYSTEM START-UP PROCEDURES

Throughout the installation procedures outlined in Section 4, emphasis has been placed on the proper plumbing and wiring of the primary system components. The solder and threaded connections also have been visually inspected for leaks and the solar loop piping has been cleaned and charged. Having successfully completed these tasks it is time to set your system to run automatically.

Set the SunEarth control to the 'ON' position. Listen until you can hear water flowing through the solar loop return piping from the collector.

Place your ear next to the pump and listen for signs of cavitation. Cavitation sounds like sand running through the pump and is caused by the implosion of small air bubbles hitting the pump impeller. Cavitation can dramatically reduce the life of the pump and the flow setting valve (COMPONENT #22) should be used to eliminate this condition. If you hear cavitation when the valve is wide open, slowly close the valve until the sound is gone.

TABLE 4

Set the SunEarth control to the 'AUTO' position. Your system is now set to run automatically whenever solar energy is available to be collected.

6) MODES OF SYSTEM OPERATION

Both single and double tank Cascade Drainback systems are designed to accommodate two separate modes of operation. Your system can either (1) serve as a preheater to your conventional electric or gas water heater or (2) be bypassed entirely and run 100% on utility power during inclement weather or when maintenance is required.

SINGLE TANK OPERATING INSTRUCTIONS:

6.1 Solar Preheat:

Leave the circuit breaker on to your solar storage tank and set the tank thermostat to the lowest acceptable temperature setting. The electric resistance heating element will come on only when the tank temperature falls below the thermostatic set point. If the solar heated water entering the tank is warmer than the thermostatic set point, the electric heating element will not come on. If you have a water heater timer, you may preset the timer to turn the heating element on and off at specified times throughout the day if desired.

Collector Array	Flowrate (GPM)
1 EP/EC-40	1.2
2 EP/EC-21	1.2
2 EP/EC-24	1.6
2 EP/EC-32	1.9

6.2 100% Utility Power:

Leave the circuit breaker to your solar storage tank on. In this mode of operation you must turn off the circulation pump. To turn the pump off, change the operational setting from automatic to "off". Failure to turn off the pump can quickly damage the pump motor, shaft, bearings or impeller.

TWO TANK SYSTEM INSTRUCTIONS:

6.3 Solar Preheat:

Follow the instructions for the single tank system for setting the thermostat, heating element or gas fired water heater or tankless gas water heater for automatic operation. Solar preheat mode operates with the collectors heating the solar storage tank and supplying this heated water into the auxiliary tank whenever there is hot water draw. The ball valves going to and from the solar storage tank (Component# 6 & 7) must be open while the bypass ball valve (Component # 5) must be closed.

6.4 100% Utility Power:

Set the thermostat for the auxiliary electric water heater, gas fired water heater or tankless gas water

heater to the desired hot water temperature. 100% Utility power mode operates by supplying mains water directly to the auxiliary heater whenever there is hot water draw, bypassing the solar storage tank. Follow the instructions for the single tank system for setting the thermostat, gas or electric heater for automatic operation. The ball valves going to and from the solar storage tank (Component # 6 & 7) must be closed while the bypass ball valve (Component #5) must be open.

7) SYSTEM SHUT DOWN AND ISOLATION PROCEDURES

Your Cascade Drainback solar water heating system is designed so that the key components can be easily isolated for emergency repairs or routine maintenance. By shutting a single valve you can isolate the entire system from the pressurized cold water supply line (COMPONENT #8). In the case of a storage tank or fitting leak immediately shut this valve and call your installation contractor for service.

The collector loop can be quickly drained if a leak is detected or for routine maintenance. Set the SunEarth control to the 'OFF' position. Next, attach a hose to the lower boiler drain (COMPONENT #11) and open the valve to drain the system.

CAUTION: THIS WATER MAY BE EXTREMELY HOT!

In two tank systems the solar storage tank can be isolated from the back-up water heater. Set the valve handles to the 100% utility power configuration as outlined above. By closing these valves the tank can be serviced or replaced. The operation of the back-up water heater will not be affected.

8) SUMMER VACATION PROCEDURES

Solar water heating systems can build up very high temperatures during summer months if there is no daily draw on the system. If a short summer vacation is planned the best way to avoid overheating in a drainback system is to set the SunEarth control to the 'OFF' position. The pump will not circulate during the day and the system will not "gain" any additional heat.

For extended vacations of a month or more SunEarth recommends that you cover the panels with a suitable opaque material. Stagnation conditions can have an adverse effect on the internal collector piping if the panel is left unprotected. SunEarth's

collector warranty specifically excludes stagnation conditions in excess of sixty days.

Remember to reset the SunEarth control to the 'AUTO' position upon your return and check the system for proper operation and draining by monitoring the water levels with the pump on and off.

9) MAINTENANCE AND TROUBLESHOOTING

The following simple procedures are intended to optimize the performance of your Cascade Drainback solar water heating system and also to extend the life of the primary components.

9.1 Checking the Water Level

It is important that the drainback reservoir remains full for proper system operation. To check the fluid level, set the SunEarth control to the 'OFF' position and allow the fluid in the array to drain into the drainback reservoir. For systems installed with an optional flow meter or sight glass, check to see that the fluid is not less than 1" from the top of the meter. If your system does not have a flow meter, unscrew the pressure relief valve (COMPONENT #9) and dip a wooden dowel into the threaded copper fitting to check that the fluid level is not more than 6-8" below the valve fitting. If a small amount of fluid is needed to bring the reservoir up to the proper level, pour it directly into the (COMPONENT #9) fitting port. Rewrap the thread with Teflon tape and reinstall (COMPONENT #9). You may also follow the instructions in section 4.13 for charging the system if more water is required.

Please remember that over time you WILL lose some fluid in the solar loop piping. If the water level is not properly maintained you may do irreparable damage to your circulating pump. Check your fluid levels at least once a year.

9.2 Replacing the Anode Rod

The second most important component in your system, at least from a longevity standpoint, is often ignored and never seen. We are referring to the sacrificial "anode rod" installed in your solar storage tank. Typically constructed from magnesium, anode rods are installed in "glass lined" water heaters and storage tanks to inhibit corrosion.

As the name implies, the "sacrificial" anode rod is consumed so that the tank lining is not. At a certain point in the process, the anode rod is no longer

completely effective and the corrosive processes begin to eat away at the tank's glass lining. In time the solar storage tank, like any other gas or electric water heater, will begin to leak. The process is not reversible and the tank must be replaced.

System temperatures and water quality affect the rate at which the anode rod is consumed. In general: the higher the average system temperature the faster the rate of corrosion. By changing the anode rod after the fifth year of system operation, and every three to five years thereafter, it is possible to extend the life of the solar storage tank. Periodic replacement of the anode rod in your solar storage tank can significantly extend the tank life.

9.3 Flushing the Storage Tank

The solar storage tank also should be flushed annually to minimize sediment buildup on the bottom of the tank. If you live in an area with high mineral content in your water, flush the tank on a semi-annual basis. Disconnect the power to the solar tank at the circuit breaker or time switch (if present) before flushing. Set the SunEarth control to the 'OFF' position. In a two tank system it is not necessary to disconnect the power to the electric water heater in order to flush the solar tank.

Open the flush valve on the bottom of the storage tank and drain a sufficient volume of water to eliminate the sediment. After the procedure is complete make sure the tank is completely full of water before restoring power to the thermostat and heating element. Set the SunEarth control to the 'AUTO' position.

9.4 Cleaning the Collector Glass

If you live in a dusty climate it is beneficial to wash off the dirt that settles on the collector glass once a month. Clean glass allows the collector to maintain a high level of thermal performance.

9.5 Maintaining Pipe Insulation

Check the exterior pipe insulation annually and patch or repair any exposed surfaces or degraded areas. Repair as necessary with manufacturer's recommended jacket or coating or a high quality exterior latex paint.

9.6 Glass Replacement

In the unusual instance of collector glass breakage, the glass should be replaced immediately. This

will reduce the likelihood of water accumulating inside the collector and deteriorating the insulation. Contact your installation contractor to change the glass.

9.7 Leaks

If you detect a water leak in the solar loop piping or tank plumbing, contact your installation contractor to service and refill the system.

9.8 Pump Not Circulating

If it's been a sunny day and you don't have hot water, first make sure that the controller is set in the automatic position. If the controller is properly set and the pump has not been running, unplug the line cord from the controller receptacle and plug the pump directly into a nearby 115 VAC outlet. If the pump does not run it may need to be replaced. If the pump does run when plugged directly into the wall outlet, the problem may be located in the controller or one of the temperature sensors. Contact your installation contractor for service.

9.9 Night Time Heat Loss

If you have a full tank of hot water before bed and the solar storage tank is cold in the morning make sure that the circulating pump is not running at night. If the pump is running and the controller displays questionable temperatures at the collector or tank (i.e. 180°F tank and 45°F collector), check both sensors using a resistance meter to see if they are correctly calibrated. If you find a defective sensor replace it immediately.

9.10 Auxiliary Electric Element not Operating

If the weather is poor and the auxiliary heating element will not fire, the bright red reset button on the thermostat may have to be depressed to be reset. Single tank systems have one heating element and thermostat. Double tank systems with conventional electric water heaters have two heating elements and thermostats.

DANGER: NEVER REMOVE THE PROTECTIVE ACCESS PLATE ON THE EXTERIOR OF THE SOLAR STORAGE TANK OR CONVENTIONAL WATER HEATER WITHOUT DISCONNECTING THE 230 VAC POWER SUPPLY AT THE CIRCUIT BREAKER.

After the circuit breaker has been turned off, remove the access plate on the storage tank or water heater and depress the red reset button on the thermostat. If it clicks when depressed the heating element should fire immediately when you reconnect the circuit breaker. If the reset button does not click and you do not have hot water after one hour, the heating element or thermostat may be defective. Contact your installation contractor for service.

In two tank systems the conventional electric water heater will be wired for electrical back-up. The solar tank will serve solely as a storage tank and will not be wired.

10) CASCADE DRAINBACK SYSTEM COMPONENT PARTS

See Figures 10, 11 and 12 for the location of the specific component numbered below.

1. SunEarth Solar Collector(s): Absorbs the sun's heat energy and transfers this heat to the heat exchange fluid (water) circulating through the collector.

2. Collector Sensor (T1): Wired to the control. Works in conjunction with the tank sensor to automatically turn your circulating pump on and off at preset temperature differentials.

3. Tank Sensor (T2): Wired to your controller. Works in conjunction with the collector sensor to turn your circulating pump on and off at preset temperature differentials.

4. Tank Outlet Sensor (T3) - Optional: Wired to your controller, this sensor shows the temperature of the hot water leaving the solar storage tank. This sensor is for information purposes only, it does not affect the control of the system.

5, 6, 7. Solar Tank Bypass Valve Assembly: For two tank systems only. Assembly of three ball valves allows the solar tank to be completely isolated and bypassed in the case of tank failure. When the solar tank is bypassed, water will be heated by the auxiliary heater only. Solar bypass valve assembly may also be a combination of two 3-way valves or a single 4-port single action bypass valve.

8. Mains Supply Line Isolation Valve: When open allows potable water to fill the solar storage tank or back-up water heater. When closed isolates the solar storage tank and back-up water heater from the pressurized city cold water supply line.

9. Pressure Relief Valve (PRV): Will discharge heat transfer fluid (water) from the collector closed loop at the PRV pressure setting, (typically 30 – 150 PSI). Under normal operating conditions, the pressure relief valve will not discharge fluid. If this valve opens and water is expelled contact your contractor immediately. This valve also can be manually opened to assist filling or draining the collector loop.

The PRV protects the collector and all components in the collector loop from pressures in excess of the PRV pressure setting.

WARNING: THE PRESSURE RELIEF VALVE SETTING MUST NOT BE HIGHER THAN THE MAXIMUM WORKING PRESSURE OF THE COMPONENTS IN THE COLLECTOR LOOP.

10. Drainback Reservoir: An insulated storage reservoir that holds the collector and solar loop piping heat exchange fluid (water) when the circulating pump is off.

11. Drain/Purge Valve: Used to charge and drain the solar loop piping.

12. Circulating Pump: Circulates water through the collector and solar loop piping.

17. Differential Temperature Controller: Automatically turns the circulating pump on and off when there is sufficient heat to be gained in the solar collector.

18. Heating Element & Tank Thermostat: The auxiliary water heater thermostat controls the temperature setting of the auxiliary heating element.

19, 20. Temperature and Pressure Relief Valve: Universally required by the plumbing code on water heaters. Will automatically release and dump water at either 150 PSI of pressure or 210° F in temperature.

21. Mixing Valve: Automatically blends hot water from the solar storage tank with incoming city cold water to an acceptable set point. A mixing valve must be installed on every Cascade Drainback solar water heating system. The mixing valve may include an integral check valve to prevent back-flow of mixed or hot water into the cold water feed line. When the mixing valve does not include an integral check valve, an external check valve should be placed on the cold feed to the mixing valve. In

two tank systems the mixing valve may be located; either at the outlet to the solar storage tank; or at the outlet to the auxiliary heater.

22. Pump Throttling Valve: May be partially closed to reduce the flow rate and prevent pump cavitation.

11) ESTIMATED COMPONENT LIFE

You can expect a long useful life from the primary components in your Cascade Drainback solar water heating system by adhering to the routine service and maintenance tips provided above.

The SunEarth solar collector and drainback reservoir have a design life of twenty-five to thirty years. The solar storage tank should last twelve to twenty years in most water quality areas provided the anode rod is periodically replaced. The circulating pump and differential control should last 10 to 15 years before needing to be replaced. Like EPA mileage estimates for automobiles, these component design lives represent average figures for drainback system components installed in the United States. The life of your components may vary.

To obtain warranty service, please see the completed Appendix on the back of this manual with your installation contractor contact information or contact SunEarth Inc. for the name of an authorized service agent near you.

12) SYSTEM OPERATING PARAMETERS

12.1 Collector Loop Pressure

The pressure in the solar collector loop should be within 0 – 20 PSIG.

12.2 Circulation Flow Rate

The flow rate in the collector loop should be 0.5 – 4 GPM when the pump first comes on (filling the collector loop). Once the collector loop is full and water starts to siphon down the return piping the flow rate will normally increase and should be 0.8 – 5 GPM with the system circulating.

12.3 Temperature Differential

The temperature difference between the collector outlet sensor (T1) and the solar tank sensor (T2) should be 4 °F – 30°F when the system is circulating.

12.4 Fluid Level

The water level when the system is not circulating (pump stopped) should such that the drainback

tank not less than 75% full. When the system is circulating (pump running); the water level in the drainback tank should be not less than 25% full. The drainback tank should never be pumped dry in normal operation as this may result in damage to the circulator pump.

APPENDIX A

CASCADE DRAINBACK OG-300 APPROVED COMPONENTS

Solar Collectors – SunEarth Liquid Flat Plate Collectors

Make	Series	Model Numbers
SunEarth	Empire, Paint	EP-21
		EP-24 EP-24-0.75 EP-24-1.5
		EP-32 EP-32-0.75 EP-32-1.5
		EP-40 EP-40-0.75 EP-40-1.5
SunEarth	Empire, Chrome	EC-21
		EC-24 EC-24-0.75 EC-24-1.5
		EC-32 EC-32-0.75 EC-32-1.5
		EC-40 EC-40-0.75 EC-40-1.5
SunEarth	SunBelt	SB-24-0.75
		SB-32-0.75
		SB-40-0.75
SunEarth	Imperial, Chrome	IC-32
		IC-40
SunEarth	Imperial, Selective	IS-32
		IS-40
SunEarth	ThermoRay	TRB-32
		TRB-40

Collector Mounting Hardware

Make	Series
SunEarth	SolarStrut
	RexRack
	Flush Mount Kit
	Universal Tilt Kit
	Landscape Rack

Install mounting hardware per SunEarth manuals, standard residential drawings, and/or plan sets.

Storage Tank with Integral Double Wall Heat Exchanger

Make	Series	Model Numbers
SunEarth	SunEarth	SU80HE-1* SU65HE-1*
		SU120HE-1*
Rheem	Soloraide	81V80HE-1* 81V80HE-T
		81V120HE-1* 81V120HE-T
		81V65HE-1*
Ruud	Solar Servant	RSPE80HE-1* RSPE80HE-T
		RSPE120HE-1* REPE120HE-T
		RSPE65HE-1*

**Includes auxiliary 4.5 kW heating element, suitable for one or two tank systems.*

Does not include auxiliary heating element, suitable for two tank systems only.

APPENDIX A

Differential Temperature Controller

Make	Series	Model Numbers
SunEarth		SETR0301U SETR0502U SETR0603mcU SETR A501 T SETR A502 TT SETR A503 TTR
Steca		TR0301U TR0502U TR0603mcU TR A501 T TR A502 TT TR A503 TTR
Independent Energy	Goldline	GL-30-X216 GL-30-X217
or Approved Equal		

Drainback Reservoir

Make	Series	Model Numbers	
SunEarth	CopperStor	DB-2.5 DB-7.5	DB-5.0 DB-10
SolarH2OT	DBT	DBT 10 SS DBT 20 SS	DBT 15 SS
Rheem	Energy Miser	81VP6S 81VP15S	81VP10S 81VP20S
or Approved Equal			

Circulator Pumps

The circulator pump shall be a wet rotor small circulator with a cast iron, stainless steel, brass or polymer body and a metal or polymer impeller. The pump motor shall be induction or permanent magnet ECM driven. The pump shall be rated for: maximum fluid temperatures of no less than 180°F and pressures of no less than 125 PSI. The maximum rated amperage shall be no more than 1.5 Amps and the maximum rated power draw shall be no more than 135 Watts.

Thermostatic Mixing Valve

The thermostatic mixing valve shall have a bronze, brass or stainless steel body with a rated maximum working temperature no less than 200°F and a rated maximum working pressure no less than 125psi. The range of temperature set points shall be at least 18°F (10°C) and shall include a set point of 120°F (50°C). The Thermostatic Mixing valve shall be third party listed and certified to one of the following ASSE standards: ASSE 1016; ASSE 1017; ASSE 1070.

APPENDIX A

Ball Valves

Ball valves shall be of bronze, brass or stainless steel construction. Maximum working temperature shall be no less than 200°F and maximum working pressure shall be no less than 125 psi.

Three-Way Valves (Optional)

Three-Way valves shall be of bronze, brass or stainless steel construction. Maximum working temperature shall be no less than 200°F and maximum working pressure shall be no less than 125 psi.

Boiler Drains (A.K.A. Charge Valves; Fill Valves; Drain Valves)

Boiler Drains shall be of bronze, brass or stainless steel construction. Maximum working temperature shall be no less than 200°F and maximum working pressure shall be no less than 125 psi.

Pressure Relief Valve

The pressure relief valve shall be of bronze, brass or stainless steel construction with a pressure setting between 30psi and 150psi. The pressure relief valve shall be set to discharge at a pressure below the maximum design pressure of all other components in the collector loop.

Thermometers (Optional)

Thermometers shall be dial or scale type and shall have a metallic body and casing and a glass lens. The range of measurement shall be not less than 30°F to 200°F with an accuracy of +/- 2%. An electronic temperature sensing system may be used in place of dial or scale thermometers (see below).

Temperature Sensors (Electronic)

An electronic temperature sensing system may be used in place of dial or scale thermometers. Temperature sensors shall be of metallic construction and have a maximum temperature rating not less than 200°F. Temperature reading may be via digital readout, LCD screen, internet or other electronic device. The temperatures may be read at the differential controller screen. The range of measurement shall be not less than 30°F to 200°F with an accuracy of +/- 2%.

Sensor Wire:

Sensor wire for temperature sensors or other electronic sensors must be no less than 18/2 AWG. Sensor wire must be insulated; in locations where the sensor wire is exposed to the elements it must be UV resistant and rated for outdoor use.

APPENDIX B

PUMP SELECTION GUIDELINES

Drainback systems operate under two different sets of conditions. The filling condition occurs when the controller activates the pump and water starts to fill the collectors. In the filling condition the pump has to overcome the system's static head (or lift) and friction head loss. The **static head** is the vertical height difference measured from the highest point in the system to the bottom of the drainback reservoir (in feet). During the filling condition the flow rate may be less than the design flow rate of the system, but should be at least 0.5 GPM in order to fill the collectors and flush all the air down the return pipe into the drainback tank.

Once the collectors and return pipe between the collectors and drainback tanks are full of water the return line will start siphoning, this counterbalances the static head. The system is now in the running condition and the pump is only required to overcome the system friction head loss. With the elimination of the static head, the pump will start to circulate the fluid at a higher flow rate (unless a variable speed pump and controller are used). In the running condition the flow rate will often be higher than the design flow rate; this is acceptable provided the fluid velocity remains below 4 ft /second. Above 4 ft /s the collector life may be reduced by erosion corrosion. A flow rate of more than the listed maximum through any collector should be avoided.

The system's static head is the most significant parameter when selecting the pump. The pump selected must have a shut off head of at least the system static head plus four feet safety factor. The larger the static head the bigger the pump required and the greater the risk of excessive flow once the system starts siphoning. To reduce the static head in buildings with multiple floors, the drainback tank should be located on the top floor, as close to the ceiling as possible. Pumps with a "steep" pump curve are also preferred, as these will operate over a smaller range of flows at different heads

Cascade drainback systems are not open to atmosphere (capped and sealed on installation). Provided the water used to fill the system is free of salts or other contaminants, a cast iron pump may be used. However, it is common for some rusting of the pump body to occur until the oxygen in the water is depleted. This rust will often circulate through the collector loop, making the fluid an unsightly brown color which will be visible in the sight glass or flow meter. If this brown water is not acceptable, or if the fluid used in the collector loop contains corrosive elements, a pump with a bronze or stainless steel body should be used.

The following pump selection tables are appropriate for all OG-300 Cascade Drainback systems, the pump selection is based on the lift required from the drainback tank to the highest point in the system (the system static head).

APPENDIX B

Low Lift Systems: 5ft - 10ft Static Head

SYSTEM PARAMETERS		PUMPS			
			Grundfos	Taco	Wilo
Static Lift Head	5 to 10 ft	Cast Iron	UP 15-100	009-F5	Star 32F
Minimum Fill Flow Rate	0.5 gpm		UPS 15-58 F*	008F6	Star 16F
Design Flow Rate	0.83 - 2.08 gpm	Stainless Steel	UP 15-100 SU7		
Heat Exchange Tank	80 or 120 gal		UPS 15-55 SF*		
1/2" Type L Supply Pipe	up to 100 ft	Bronze	UP 26-96 BF	009-BF5	Star 32BF
3/4" Type L Return Pipe	up to 100 ft			008-BF/BC6	Star 16BF

*REMOVE INTEGRAL CHECK VALVE FROM PUMP IF INCLUDED

Medium Lift Systems: 10ft - 30ft Static Head

SYSTEM PARAMETERS		PUMPS			
			Grundfos	Taco	Wilo
Static Lift Head	10 to 30 ft	Cast Iron	UP 15-100	009-F5	Star 32F
Minimum Fill Flow Rate	0.5 gpm				
Design Flow Rate	0.83 - 2.08 gpm	Stainless Steel	UP 15-100 SU7		
Heat Exchange Tank	80 or 120 gal				
1/2" Type L Supply Pipe	up to 100 ft	Bronze	UP 26-96 BF	009-BF5	Star 32 BF
3/4" Type L Return Pipe	up to 100 ft				

High Lift Systems: Over 30ft Static Head

For systems with static head in excess of 30ft no single small circulator pump will be able to fill the system. In these cases it may be necessary to stack two pumps in series. A combination of two of the approved pumps in the tables above should be used. The total pumping head available will be the sum of the two pumps' shut off heads. When pumps are stacked in this way, the controller should be set to turn on both pumps at once, but one of the pumps is controlled through a time delay relay. Both pumps are turned on to fill the system, after 5 minutes one of the pumps is turned off and the system continues to operate with just one pump in the running condition.

APPENDIX C

CASCADE DRAINBACK SYSTEM & COMPONENT LABELS

Labels containing the text below shall be attached to the appropriate valves on all SRCC OG-300 certified systems.

FLUID IDENTIFICATION:

THE HEAT TRANSFER FLUID USED IN THIS SYSTEM IS WATER. NO OTHER FLUID SHALL BE USED THAT WOULD CHANGE THE ORIGINAL CLASSIFICATION OF THIS SYSTEM.

BE EXTREMELY CAREFUL WHEN DRAINING THIS FLUID. IT MAY BE DISCHARGED AT A VERY HIGH TEMPERATURE AND PRESSURE.

HEAT EXCHANGER

THE HEAT EXCHANGER USED IN THIS SYSTEM IS DOUBLE WALL VENTED TO ATMOSPHERE. THE HEAT EXCHANGER IS INTEGRAL TO THE SOLAR STORAGE TANK.

FREEZE LABEL:

THE CASCADE DRAINBACK SYSTEM IS PROTECTED FROM FREEZING BY AUTOMATICALLY DRAINING THE SOLAR COLLECTORS AND EXPOSED PIPING WHENEVER THE CIRCULATION PUMP SHUTS OFF. WHEN PROPERLY INSTALLED AND OPERATED THE SYSTEM IS PROTECTED TO TEMPERATURES AS LOW AS -50 F.

BOILER DRAIN NO. 11 – SYSTEM FILL & DRAIN VALVE

VALVE 11 IS NORMALLY CLOSED. WHEN OPENED IN CONJUNCTION WITH PRV (COMPONENT # 9) IT IS USED TO CHARGE AND DRAIN THE SOLAR COLLECTOR LOOP PIPING.

THE HEAT TRANSFER FLUID USED IN THIS SYSTEM IS WATER. NO OTHER FLUID SHALL BE USED THAT WOULD CHANGE THE ORIGINAL CLASSIFICATION OF THIS SYSTEM. UNAUTHORIZED ALTERATIONS TO THIS SYSTEM COULD RESULT IN A HAZARDOUS HEALTH CONDITION.

BE EXTREMELY CAREFUL WHEN DRAINING THIS FLUID. IT MAY BE DISCHARGED AT A VERY HIGH TEMPERATURE AND/OR PRESSURE.

VALVE NO. 8 - COLD WATER SUPPLY ISOLATION VALVE

THIS VALVE IS NORMALLY OPEN AND ALLOWS POTABLE WATER TO FILL THE SOLAR STORAGE TANK. WHEN CLOSED THE SOLAR STORAGE TANK IS ISOLATED FROM THE PRESSURIZED CITY COLD WATER SUPPLY LINE PIPING.

APPENDIX C

VALVE NO. 22

VALVE 22 IS NORMALLY OPEN. IT MAY NECESSARY TO PARTIALLY CLOSE VALVE 22 TO PROTECT THE PUMP FROM CAVITATION BY REDUCING FLOW RATES IN THE COLLECTOR LOOP.

PRESSURE RELIEF VALVE (COMPONENT #9)

THE PRV WILL AUTOMATICALLY OPEN AND DISCHARGE FLUID OR AIR IN THE EVENT OF THE COLLECTOR LOOP PRESSURE EXCEEDING THE MAXIMUM WORKING PRESSURE OF THE SYSTEM.

WHEN FILLING OR DRAINING THE SYSTEM THROUGH BD, THE PRV IS MANUALLY OPENED OR REMOVED FROM THE COLLECTOR LOOP IN ORDER TO ALLOW AIR TO FLOW IN OR OUT OF THE COLLECTOR LOOP.

ADDITIONAL TWO TANK SYSTEM VALVES

VALVE NO. 7 – COLD FEED TO SOLAR TANK ISOLATION VALVE

THIS VALVE IS NORMALLY OPEN. WHEN CLOSED IN CONJUNCTION WITH VALVE NO. 6 IT WILL ISOLATE THE SOLAR STORAGE TANK FROM THE POTABLE WATER SYSTEM.

VALVE NO. 6 – HOT OUTLET FROM SOLAR TANK ISOLATION VALVE

THIS VALVE IS NORMALLY OPEN. WHEN CLOSED IN CONJUNCTION WITH VALVE NO. 7 IT WILL ISOLATE THE SOLAR STORAGE TANK FROM THE POTABLE WATER SYSTEM.

VALVE NO. 5 – SOLAR TANK BYPASS VALVE

THIS VALVE IS NORMALLY CLOSED. WHEN OPENED IN CONJUNCTION WITH CLOSING VALVES NO. 6 & 7 IT WILL ALLOW COLD WATER TO BYPASS THE SOLAR SYSTEM AND FEED DIRECTLY INTO THE AUXILLIARY WATER HEATER.

APPENDIX D



SUN EARTH INC.
Quality Solar Energy Products

TEN-YEAR LIMITED PRODUCT WARRANTY

This warranty only applies to the following SunEarth products (hereinafter SunEarth Products):

COLLECTORS: Empire, Imperial, SunBelt, SunWise, and Custom Collectors

ABSORBERS: SunBurst and Custom Absorber Plates used in any glazed application

ICS AND DRAINBACK: CopperHeart ICS, CopperHeart Tanks, and CopperStor DrainBack Tanks

Under conditions of normal use and service the above SunEarth Products are warranted to the original, or subsequent users, for a period of **10 years** from the date of sale to be free of defects in material and workmanship pursuant to the exclusions detailed in this written warranty statement. SunEarth's liability for these products shall be limited to repairing or replacing at SunEarth's option, without charge, F.O.B. SunEarth's factory or an authorized SunEarth distributor or service center. SunEarth will not be liable for any costs of transportation, inspection, removal, reinstallation, or any other labor or freight charges that may arise in connection with a warranty claim, except as expressly set forth in this warranty.

The use of **ANY** of the above SunEarth Products for pool or spa heating is **NOT** covered by this warranty, **UNLESS** the pool or spa water is isolated from the above SunEarth Products through the use of a heat exchanger.

FIELD LABOR

Field labor to repair or replace any defective SunEarth Product is reimbursable as follows:

Year 1	\$100/collector
Year 2 ~ 5	\$75/collector
Year 6 ~ 10	\$50/collector

FREIGHT AND SHIPPING EXPENSES

In the event of a valid warranty claim approved by SunEarth, SunEarth will pay for freight and shipping expenses as follows:

Year 1 of Warranty: SunEarth will pay the freight and shipping costs for the new or repaired SunEarth Product between SunEarth and the nearest local distributor, dealer, authorized service center, city, or shipping terminal.

After Year 1 of Warranty: Freight and shipping costs are the responsibility of the owner.

THIS WARRANTY DOES NOT APPLY

This warranty **does not apply** to the following: (1) conditions resulting from a failed component or part that is not part of the above listed SunEarth Products; (2) to damage caused by freezing conditions; (3) to conditions resulting from misuse, abuse, neglect, accident, or alteration; (4) to cosmetic discoloration of the collector framewall, absorber plate, or glazing over time; (5) to glass breakage; (6) to conditions resulting from the introduction of harmful chemicals, caustic fluids, or liquids deleterious to copper tubing, including improperly applied or maintained heat transfer fluids or chlorinated pool or spa water; (7) to SunEarth Products in which heat transfer fluids other than potable water or propylene glycol (DowFrost HD

Effective 01/17/11

Protecting Our Environment – Since 1978

www.sunearthinc.com

APPENDIX D

recommended) was used; (8) to propylene glycol pH levels above 10 or below 8; (9) to periods of stagnation in excess of 30 days; (10) to excessive pressure; (11) to erosion corrosion of the copper tubing resulting from excessive flow rates; (12) to improper plumbing configurations that do not conform to SunEarth's manifolding requirements; (13) to clouding or condensation naturally resulting from temporary intrusions of moisture into the collector; (14) to conditions resulting from floods, earthquakes, winds, fire, lightning, or circumstances beyond SunEarth's control; (15) to damage caused by installation methods, including mounting, that do not conform to relevant national, state or local codes and ordinances, good industry practices, or to current applicable SunEarth manuals, diagrams, technical bulletins, or written installation instructions; (16) or to applications other than medium temperature (110 - 160F) domestic water heating.

If one of the above SunEarth Products is purchased outside the United States certain conditions of this warranty may **NOT** apply. Please contact your local SunEarth distributor or dealer for details.

LIMITED WARRANTY

EXCEPT AS EXPRESSLY PROVIDED IN THIS WARRANTY, THE ABOVE SUNEARTH PRODUCTS ARE PROVIDED WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE OR ANY WARRANTY OR NON-INFRINGEMENT. SOME STATES DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES, SO THE ABOVE EXCLUSION MAY NOT APPLY TO YOU.

LIMITATIONS OF REMEDIES

IN NO EVENT SHALL SUNEARTH BE LIABLE FOR ANY DAMAGES FOR LOST PROFITS, LOST SAVINGS OR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES, ARISING OUT OF THE USE OR INABILITY TO USE THE ABOVE SUNEARTH PRODUCTS, OR FOR ANY CLAIM BY A THIRD PARTY. SOME STATES DO NOT ALLOW THE LIMITATION OR EXCLUSION OF LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

EXCLUSIVE AGREEMENT

THIS WARRANTY CONSTITUTES THE ENTIRE, COMPLETE, FINAL, AND EXCLUSIVE AGREEMENT FOR THE SUNEARTH PRODUCTS LISTED ABOVE. THIS WARRANTY SUPERSEDES ANY PROPOSAL, AGREEMENT, OR REPRESENTATION, OR ANY OTHER COMMUNICATION, EITHER WRITTEN OR ORAL, MADE BETWEEN SUNEARTH AND SUNEARTH'S DISTRIBUTORS OR DEALERS, OR BETWEEN SUNEARTH AND THE END CONSUMER.

TO MAKE A CLAIM

To obtain service under this warranty, the product in question must be returned to the distributor or dealer of SunEarth products nearest you, or an authorized SunEarth service center. Each claim must be accompanied by documentation providing the following:

- 1) Owner's name, address, email address, and phone number
- 2) Installation contractor's name, email address, and phone number
- 3) Original sales receipt
- 4) Product model and serial number(s)
- 5) Date of installation
- 6) Date of failure
- 7) Reason for failure
- 8) Pictures of the suspected manufacturing defect – digital pictures of the suspected manufacturing defect also need to be submitted

If you have any warranty questions, contact your installation contractor or SunEarth at (909) 434-3100.

Effective 01/17/11

Protecting Our Environment – Since 1978

www.sunearthinc.com

APPENDIX G



Solar Rating & Certification Corporation™
The Industry Standard Since 1980.

OG-300 Certification Page Artwork

The Supplier is responsible for having a page in the installation and operation manual(s) with only the following table on it. It can be anywhere in the manual. SRCC will provide the artwork and no changes are allowed.

The solar system installer is to indicate (circle, check, etc.) the system that was actually installed.

	This product certified by: Solar Rating & Certification Corporation™ www.Solar-Rating.org	SunEarth, Inc. 8425 Almeria Avenue Fontana, CA 92335 USA
Solar Energy Factor (SEF ₀)	SRCC Cert. No.	System Model:
2.70	2001026J	EPRD-64-120
3.60	2001026K	EPRD-80-120
3	2001026M	ECRD-64-120
2.10	2001026B	ECRD-40-80
2	2001026C	EPRD-42-80
2.20	2001026E	EPRD-48-80
2.40	2001026F	ECRD-48-80
3.70	2001026H	ECRD-64-80
1.60	2001027A	EPRD-40-80-2
1.60	2001027C	EPRD-42-80-2
1.80	2001027E	EPRD-48-80-2
1.90	2001027F	ECRD-48-80-2
2.30	2001027G	EPRD-64-80-2
2.50	2001027H	ECRD-64-80-2
1	2001028A	EPRD-40-80-2G
1	2001028B	ECRD-40-80-2G
1.80	2001026I	EPRD-40-120
1.90	2001026L	ECRD-40-120
2	2001026A	EPRD-40-80
3.20	2001026G	EPRD-64-80
1.70	2001027B	ECRD-40-80-2
4.60	2001026N	ECRD-80-120

The installed system is marked above.

APPENDIX G



Solar Rating & Certification Corporation™
The Industry Standard Since 1980.

OG-300 Certification Page Artwork

The Supplier is responsible for having a page in the installation and operation manual(s) with only the following table on it. It can be anywhere in the manual. SRCC will provide the artwork and no changes are allowed.

The solar system installer is to indicate (circle, check, etc.) the system that was actually installed.

	This product certified by: Solar Rating & Certification Corporation™ www.Solar-Rating.org	SunEarth, Inc. 8425 Almeria Avenue Fontana, CA 92335 USA
Solar Energy Factor (SEF _D)	SRCC Cert. No.	System Model:
1	2001028C	EPRD-42-80-2G
0.90	2001028M	ECRD-32-120-2G
1.10	2001028F	ECRD-48-80-2G
1.30	2001028G	EPRD-64-80-2G
1.40	2001028H	ECRD-64-80-2G
1	2001028I	EPRD-64-80-75G
0.90	2001028J	EPRD-64-80-100G
0.90	2001028K	ECRD-32-80-2G
0.90	2001028L	EPRD-32-80-2G
1	2001028N	ECRD-40-120-2G
1.30	2001028P	ECRD-64-120-2G
0.90	2001028Q	EPRD-32-120-2G
1	2001028R	EPRD-40-120-2G
1	2001028S	EPRD-48-120-2G
1.20	2001028T	EPRD-64-120-2G
1.60	2001028V	ECRD-80-120-2G
1.10	2001028O	ECRD-48-120-2G
1.40	2001028U	EPRD-80-120-2G
1.10	2001028E	EPRD-48-80-2G

The installed system is marked above.

APPENDIX G



Solar Rating & Certification Corporation™
The Industry Standard Since 1980.

OG-300 Certification Page Artwork

The Supplier is responsible for having a page in the installation and operation manual(s) with only the following table on it. It can be anywhere in the manual. SRCC will provide the artwork and no changes are allowed.

The solar system installer is to indicate (circle, check, etc.) the system that was actually installed.

	This product certified by: Solar Rating & Certification Corporation™ www.Solar-Rating.org	SunEarth, Inc. 8425 Almeria Avenue Fontana, CA 92335 USA
Solar Energy Factor (SEF _D)	SRCC Cert. No.	System Model:
1.90	2008025C	ECRD-48-80-TLG
2.60	2008025H	EPRD-64-80-TLG
1.30	2008025I	ECRD-32-120-TLG
1.50	2008025N	EPRD-40-120-TLG
2.50	2008025L	ECRD-64-120-TLG
3	2008025Q	EPRD-80-120-TLG
1.70	2008025O	EPRD-48-120-TLG
2.20	2008025P	EPRD-64-120-TLG
3.90	2008025R	ECRD-80-120-TLG
1.30	2008025M	EPRD-32-120-TLG
1.70	2008025B	ECRD-40-80-TLG
1.40	2008025E	EPRD-32-80-TLG
1.80	2008025G	EPRD-48-80-TLG
1.50	2008025J	ECRD-40-120-TLG
1.80	2008025K	ECRD-48-120-TLG
1.40	2008025A	ECRD-32-80-TLG
3	2008025D	ECRD-64-80-TLG
1.60	2008025F	EPRD-40-80-TLG

The installed system is marked above.

APPENDIX H



Service & Warranty Information

Contractor/Installer Information

Name: _____

Company: _____

Address: _____

Phone: _____

Email: _____

System Info

Model No. _____

Date Purchased: _____

Date Installed: _____

Product Serial Number: _____

For Service and Repair Contact: _____

Comments: _____



8425 Almeria Avenue • Fontana, CA 92335

Phone: (909) 434-3100 • Fax: (909) 434-3101

email: sales@sunearthinc.com • www.sunearthinc.com

Revised 3-16-16